

Performance Indicators for DPA


Indicators With Memory

These indicators are normally used for controlling casual excess pressure at main lines and secondary lines.


When pressure becomes excessive, device is actuated and remains in that position until its return is manually done. It is recommended to do that only after reason and location of failure has been discovered.

Code	Reference	Marking	Minimum Pressure
5252	09.710.2	50	50
5253	09.710.3	75	75
5249	09.710.4	100	100
11085	09.710.5	150	150
5250	09.710.6	200	200
5251	09.710.7	250	250

Application of divider model DPA



Rod indicator with memory



Purchasing information:
Please refer to page PRO-47