


Divider Model DPM With Visible Rod

Description

Visible controlling rods allow visualizing piston displacement and proper operation of the whole system. Normally it is connected to the main divider (master), however, as it may not signalize casual damages to secondary lines, it is recommended, if possible, to install one at all and each secondary divider.

Rod movement is possible due to displacement of metering piston adapted to the rod. Visible rods may not be used in continuous operation systems. If that is the case (continuous operation), it is necessary to modify visual control into electrical. It is possible to adapt the body of visual indicator to the electrical control microprocessor housing.

When ordering, please specify whether visual control is to be installed at inlet right or left side, by adding to the code of divider letter "D" if to the right side or "E" if to the left side.



Purchasing codes

Code	Reference	Nº of pistons
5214	02.881.3	3
5215	02.881.4	4
5216	02.881.5	5
5217	02.881.6	6
5218	02.881.7	7
5219	02.881.8	8
5220	02.881.9	9
5221	02.882.0	10

Purchasing information:

Please refer to page PRO-47